


5

Type	Range	Accuracy
385, 4 Wire	-200°C to 850°C	0.3°C
385, 3 Wire	-200°C to 850°C	0.3°C
385, 2 Wire	-200°C to 850°C	0.6°C
392, 4 Wire	-200°C to 660°C	0.3°C
392, 3 Wire	-200°C to 660°C	0.3°C
392, 2 Wire	-200°C to 660°C	0.6°C
3916, 4 Wire	-200°C to 660°C	0.3°C
3916, 3 Wire	-200°C to 660°C	0.3°C
3916, 2 Wire	-200°C to 660°C	0.6°C

## Setting Alarms

Alarms are set by clicking the  icon on the desired input signal found in the **Inputs** configuration tab. Setup the threshold and alarm type in the **Condition** section and then select which output to turn on in the **Action** section. The alarm can be set to be latching or non-latching in the **Recovery** section.

Condition:  
 Sensor:  Above  for  s  
 Action:  
 Transmit Notification   
 Turn On   
 Change   (s)  
 Recovery:  
 Duration (s)  And  Transmission interval

## ON/OFF Control

To configure ON/OFF Control on a device, navigate to the **Output Configuration Tab** in SYNC and click on the icon located to the right of the available outputs. Clicking the icon will open the **Define ON/OFF Control** dialog box as seen below. Choose the input with the active alarm that you would like to control and set your preferred parameters.

Define ON/OFF Control - Output0

Enable Control

Inputs  Setpoint


Output  Control Actions  DeadBand

Save Cancel

6

The **Setpoint** establishes the target process value and the **Deadband** establishes the range from the Setpoint that the process value can accept before the output is activated. When **Reverse** control is selected, the output is on when the process value is below the **Setpoint**. When **Direct** control is selected, the output is on when the process value is above the **Setpoint**. Once the ON/OFF Control parameters have been set, click save to finalize the settings.

## Specifications



	Name	Function
Pin 1	DIO 0	Discrete I/O Signal 0
Pin 2	INTR	Interrupt Signal
Pin 3	SCL	I2C Clock Signal
Pin 4	SDA	I2C Data Signal
Pin 5	Shield	Shield Ground
Pin 6	DIO 1	Discrete I/O Signal 1
Pin 7	GND	Power Ground
Pin 8	3.3VDD	Power Supply

### INPUT POWER

**Voltage:**  $2.8 V_{DC} - 3.3 V_{DC}$

### DIO DIGITAL INPUTS

$$V_{inHighThreshold} = 2.2 V_{MAX}$$

$$V_{inLowThreshold} = 0.3 V_{MIN}$$

$$V_{inMAX} = 30 V_{DC}$$

### DIO DIGITAL OUTPUTS

2x Open Drain 100 mA max  
 $V_{MAX} = 30 V_{DC}$

### ENVIRONMENTAL

**Operating Temperature:** -40 to 85°C (-40 to 185°F)  
**Rating:** IP67 when mated

### MECHANICAL

**Dimensions:** 22.1 mm W x 96.7 mm L (0.87" x 3.80")  
 not including mounting tabs

### GENERAL

**Agency Approvals:** CE, EMC 2014/30/EU, LVD 2014/35/EU  
**Configuration:** Configurable via IF-001 USB Adaptor and SYNC configuration software  
**Software:** Compatible with OEG and SYNC configuration software

## WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components in which wear is not warranted, include but are not limited to contact points, fuses, and triacs.

**OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by the company will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.**

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

## RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair or calibration,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a trademark of OMEGA ENGINEERING, INC.  
 © Copyright 2019 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.

QUICK START

CE

layer



Probe not included

SP-005

Temperature and RTD Smart Probe

omega.com info@omega.com

**Servicing North America:**

**U.S.A. Headquarters:** Omega Engineering, Inc.  
 800 Connecticut Ave. Suite 5N01, Norwalk, CT 06854  
 Toll-Free: 1-800-826-6342 (USA & Canada only)  
 Customer Service: 1-800-622-2378 (USA & Canada only)  
 Engineering Service: 1-800-872-9436 (USA & Canada only)  
 Tel: (203) 359-1660 Fax: (203) 359-7700  
 e-mail: info@omega.com

**For Other Locations Visit [omega.com/worldwide](http://omega.com/worldwide)**

The information contained in this document is believed to be correct, but OMEGA accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

## Introduction

Use this Quick Start Guide to set up your Layer N SP-005 Temperature Monitoring and Control Smart Probe. For additional information regarding your SP-005, refer to the User Manual available on the Omega website.

## Materials

### Included with your SP-005

- SP-005 Unit
- Quick Start Guide
- M12 5-Pin B Code Screw Terminal accessory available on the Omega website

-Part Number: M12-S-M-FM

### Additional Materials Needed

- Layer N Smart Interface
- Computer/Laptop with Windows OS
- SYNC configuration software  
-Downloadable on the Omega website
- RTD or Thermocouple wires

**Important:** A Layer N Smart Interface is required to connect your SP-005 to SYNC configuration software.

## Before you Begin

**Important:** If you would like to take advantage of the SP-005's plug-and-play feature, simply connect the **Smart Probe** to your **Gateway** with your preferred **Smart Interface** or **wireless transmitter** to begin displaying sensor readings. To adjust the software adjustable features, continue with this quick start guide.

To properly setup the SP-005, ensure the following prerequisites are met:

- Ensure SYNC is downloaded, setup, and running before continuing.
- Ensure you have a Smart Interface compatible with your Smart Probe and your computer running SYNC.

## Thermocouple or RTD Connection

Most M12 thermocouple and RTD probes can be connected directly to the SP-005.

**Step 1:** Assemble your SP-005 by connecting thermocouple or RTD probe to the M12 4-Pin connector of your SP-005.

**Important:** If you are connecting wires directly to the SP-005, view the wiring diagrams provided in the sections titled **Thermocouple Interface and Wiring** or **RTD Interface and Wiring** to correctly wire your device.

## Connecting your Smart Probe & Interface

**Step 1:** Connect the SP-005 to your Smart Interface.

**Note:** Locate the position of the keyway as a guide on the SP-005 prior to making the connection.

**Step 2:** Connect the Smart Interface or Wireless Transmitter to your computer.


## SYNC Auto-Detect

Once the SP-005 is connected to your computer, SYNC will automatically detect it and begin displaying temperature readings.


**Note:** If you have successfully connected your SP-005 to SYNC, skip ahead section **Thermocouple Interface and Wiring** or **RTD Interface and Wiring**.

## SYNC Manual Connection


If SYNC does not automatically detect your device, follow these steps:

**Step 1:** Click on the  icon located on the top left of the SYNC interface.

**Step 2:** Select End Device / Probe and click **Next**.




**Step 3:** Select your **Communication Interface** type from the dropdown and set your preferred Command Timeout, Device Address, and Device ID / Port.



**Step 4:** Click **Finish**.

## Thermocouple Interface and Wiring


The SP-005 provides interfaces to type J, K, T, E, N, R, S, B, and C thermocouples with the capability of enabling or disabling the open detect feature. To use these features, follow these steps:



**Step 1:** Click the **Inputs** configuration tab on SYNC and choose your input type from the **Type** drop down.

**Step 2:** Click the input you wish to configure and select your thermocouple type from the **Device Range/Type** drop down.

**Step 3:** Click the **Open Detect** drop down and choose to enable or disable it.




Type	Range	Accuracy
J	-210°C to 1200°C	0.4°C
K	160°C to 1372°C	0.4°C
T	190°C to 400°C	0.4°C
E	-220°C to 1000°C	0.4°C
N	-100°C to 1300°C	0.4°C
R	40°C to 1768°C	0.5°C
S	100°C to 1768°C	0.5°C
B	640°C to 1820°C	0.5°C
C	0°C to 2320°C	0.4°C


## Cold Junction Compensation

The thermocouple input interface offers cold junction compensation calibration. To achieve proper Ice Point Calibration, you must be able to immerse your thermocouple into an environment that is stabilized at 0°C (32°F).

**Step 1:** Change the input type to **Single TC** or **Dual TC** using SYNC and click **Calibration** beneath the input interface.



**Step 2:** Follow the instructions on how to reach a temperature of 0°C as displayed on SYNC. Once the Thermocouple is stable in a 0°C environment, click **Calibrate**.




One-Point calibration allows calibration using any arbitrary temperature for thermocouples that do not measure down to 0°C (32°F)

## RTD Interface and Wiring

The SP-005 provides interfaces to type 100, 500, and 1000 ohm 392 Curve, 100 ohm 3916 curve RTD devices in 2, 3, and 4 wire configurations. To use these features, follow these steps:


**Note:** A single RTD connection is supported.



**Step 1:** Click the **Inputs Configuration** Tab on SYNC and choose your input type from the **Type** drop down.

**Step 2:** Click the input you wish to configure and select your RTD type from the **Device Range/Type** drop down.

**Step 3:** Click the **Wire** drop down and choose your wiring configuration.



• **2 Wire RTD Connections:** Most useful with high-resistance sensors or in applications where a great deal of accuracy is not required.

• **3 Wire RTD Connections:** This connection is best suited for devices like strain gauges and is most often seen in industrial process and monitoring applications.

• **4 Wire RTD Connections:** A 4 Wire configuration is primarily used in laboratories and other settings where great accuracy is necessary.