


Quick Start for Analog/Temp/RH/Light (MX1104) & 4-Channel Analog (MX1105) Loggers

1   Download HOBObconnect™ to your phone or tablet.

2 Open the app. Enable Bluetooth® in your device settings if prompted.



3 Install any external self-describing sensors as shown.






For other types of external analog sensors, insert the sensor plug into an analog sensor port.


4 Press either button on the logger to wake it up.

5 Tap Devices in the app. Tap the logger in the app to connect to it. (Press the top button on the logger again to bring it to the top of the list if there are multiple loggers.) If the logger does not appear in the list, make sure it is within range of your mobile device.

6 a. Once connected, tap  to set up the logger.
b. Choose your logger settings, including selecting settings for any external analog sensors. Make sure all channels you want to log are enabled.
c. Tap  to save the settings to the logger. The logger will begin logging based on the settings you selected. Press the start button on the logger if you set it up to start logging with a button push.

7 Deploy the logger to the location where you will be monitoring the conditions. Insert one of the included plugs into any empty ports. Follow additional deployment guidelines in the full product manual.

8 To offload data from the logger to your device, tap Devices and press the button on the logger to wake it up (if necessary). Connect to the logger and tap . To view, export, and share the data, tap HOBOb Files, tap , and then tap .

	Quick Reference	Press for 1 second to:	Press and hold for 3 seconds to:	Press and hold for 10 seconds to:
	Top button	<ul style="list-style-type: none"> • Cycle through each channel to view the latest sensor readings • Wake up the logger • Bring the logger to the top of the list in the app • Silence a beeping alarm • Turn on LCD 	Start, stop, or resume logging (depending on settings chosen in the app)	NA
	Bottom button	<ul style="list-style-type: none"> • Cycle through any statistics and alarm readings for the channel currently displayed (if applicable) • Wake up the logger • Silence a beeping alarm • Turn on LCD 	Clear an alarm for the channel currently displayed (depending on the settings chosen in the app)	NA
	Both buttons	NA	NA	Reset a password

www.jakar.cz • e-mail: sales@jakar.cz • phone: +420 596 311 899